







How to change front anti roll bar bushes on Opel Corsa S93 replacement guide



#### **VIDEO TUTORIAL**

#### (i) Important!


This replacement procedure can be used for: OPEL COMBO (71\_) 1.4, OPEL CORSA B (S93) 1.4 i (F08, F68, M68), OPEL CORSA B Box (S93) 1.4 i (F08, W5L)

The steps may slightly vary depending on the car design.

WWW.AUTODOC.CO.UK 1–12



#### REPLACEMENT: ANTI ROLL BAR BUSHES – OPEL CORSA S93. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Drive socket # 13

- Ratchet wrench
- Torque wrench
- Hydraulic transmission jack

WWW.AUTODOC.CO.UK 2–12



## Replacement: anti roll bar bushes – Opel Corsa S93. AUTODOC recommends:

- Both stabilizer bushes should be replaced simultaneously.
- The replacement procedure is identical for the right and left stabilizer bushes.
- All work should be done with the engine stopped.

### REPLACEMENT: ANTI ROLL BAR BUSHES – OPEL CORSA S93. USE THE FOLLOWING PROCEDURE:


1



Lift the car using a jack or place it over an inspection pit.

WWW.AUTODOC.CO.UK 3–12





Clean the fasteners of the stabilizer bush brackets. Use a wire brush. Use WD-40 spray.

3



Unscrew the fasteners of the stabilizer bush brackets. Use a drive socket #13. Use a ratchet wrench.

WWW.AUTODOC.CO.UK 4–12





Remove the stabilizer bush brackets.

6



Remove the stabilizer bushes.

7

Clean the mounting seats of the stabilizer bushes. Use a wire brush. Use WD-40 spray.


WWW.AUTODOC.CO.UK 5–12






Install the new stabilizer bushes.

9



Install the stabilizer bush brackets.

WWW.AUTODOC.CO.UK 6–12



Screw the fasteners of the stabilizer bush brackets. Use a drive socket #13. Use a torque wrench. Tighten it to 65 nm torque.

11

Treat the fasteners of the stabilizer bush brackets. Use copper grease.

12



Lower the car.

WWW.AUTODOC.CO.UK 7–12



# DID YOU FIND THESE INSTRUCTIONS HELPFUL?

YES

NO




**BECOME A MEMBER OF AUTODOC CLUB!** 

WWW.AUTODOC.CO.UK 8–12



### AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE





WWW.AUTODOC.CO.UK 9–12







WWW.AUTODOC.CO.UK 10–12







WWW.AUTODOC.CO.UK 11–12





#### i Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.

WWW.AUTODOC.CO.UK 12–12